TSE 3003

Mode selection

TSE 3003 – Mode selection

Lite Mode → Standard Mode :

Press the ON/Enter key.
Press the function key.
Press key 2 twice (menu option [Standard Mode]).
Press the ON/Enter key.
Enter your opening code.
Enter your 4-digit code 3195.
Press the ON/Enter key.
To switch to Standard mode, confirm the setting again
with the ON/Enter key.

Standard Mode → Lite Mode :

Press the ON/Enter key.
Press the function key.
Select the menu option [Administrator] using keys 1 and 2.
Press the ON/Enter key.
Select the menu option [Lite Mode] using keys 1 and 2.
Enter your valid administrator code.
Enter the 4-digit code 7293.
Press the ON/Enter key.
To switch to Lite-Mode, confirm the setting again with the ON/Enter key.

Important !

All extended settings such as user, calendar, time switch ... are re-set (deleted !) when converting the
locking system from Standard to Lite Mode. The first 6 digits of the Administrator code are then the
normal user code as only a 6-digit code can be programmed in Lite Mode.

Burg-Wächter KG

Altenhofer Weg 15
D - 58300 Wetter
Germany

www.burg-waechter.de
info@burg-waechter.de

Omissions and changes reserved
Irrtum und Änderungen vorbehalten
Sous réserve de fautes d'erreurs et de modifications
Errores y modificaciones reservadas
Errori e cambiementi riservati
Fouten en wijzigingen voorbehouden

BA/A TSE   HJW   02/2005