










Quick Start  
secuENTRY Home  
ENTRY 5001 PIN 1







Quick Start  
secuENTRY Home  
ENTRY 5001 PIN 2















Quick Start  
secuENTRY Home  
ENTRY 5001 PIN 3




Quick Start  
secuENTRY Home  
ENTRY 5001 PIN 4




Quick Start  
secuENTRY Home  
ENTRY 5001 PIN 5



3



4



Quick start  
secuENTRY HOME  
ENTRY 5001 PIN

secuENTRY



Hauptanleitung:  
Main manual:  
Manuel Principal :  
Hoofdgebruiksaanwijzing:  
[www.burg.biz](http://www.burg.biz)

